









control functions




crown positions

TIME ADJUST   

DATE ADJUST     


DIVE READY  
water resistant to 100m.     




*Note: with the Crown out, your watch is water resistant to only 30m. Before your dive, make sure the Crown is tightly secured to ensure 100m water resistance.*

specifications

WATCH MATERIALS

crystal  
mineral glass  
casing  
stainless-steel  
caseback  
stainless-steel  
strap  
urethane  
buckle  
stainless-steel

BATTERY

type of battery  
SR626SW  
battery life  
approx. 2 years

WATER RESISTANCE

100 meters  
*(only 30m if Crown is unscrewed)*

ONE YEAR LIMITED WARRANTY

Your Nike watch is warranted to be free of defects in materials or workmanship, under normal use, for a period of one year from the date of original retail purchase. This limited warranty excludes the battery, crystal, strap, or damage resulting from improper care or handling, accidents, modification, unauthorized repairs, or normal wear.

Return the defective watch and the store receipt to the place of purchase. If there is a covered defect, the defective parts or watch will be repaired or replaced, at Nike's option, with the same product (if available) or a similar product of equal price.

This limited warranty is in lieu of all other express or implied warranties, and excludes refund of the purchase price. In no event shall Nike be liable for direct, indirect, incidental or consequential damages arising out of the use of the watch, and any recovery is limited to the purchase price. No other person or company is authorized to change this warranty, and your dealer is solely responsible for any other warranties.

Your Nike watch is a precision sport time piece, sealed at the factory for water-resistance. In order to maintain your watch's warranty, functionality and water-resistance, all service including battery replacement must be performed at an authorized service center.

If your Nike watch has a translucent colored strap, the strap's color and translucence may fade over time due to exposure to UV radiation, your skin's pH factor, sweat and strong dyes in clothing. Any such discoloration and fading is not covered by the warranty.



www.nike.com  
printed in Hong Kong  
© 2000 Nike, Inc. All rights reserved.

REPAIR CENTERS

<b>Finland</b> 0800-113 198	<b>Norway</b> 800-11 375
<b>France</b> 0800- 903 186	<b>Portugal</b> 05-05 31 33 66
<b>Germany</b> 0130-81 04 33	<b>Singapore</b> 65-788 0990
<b>Hong Kong</b> 852 2751 4988	<b>South Africa</b> 0800 11 64 77
<b>Italy</b> 800-79 03 16	<b>Spain</b> 900-98 31 74
<b>Ireland</b> 1-800 55 31 48	<b>Sweden</b> 020-79 81 57
<b>Japan</b> 0120-500-719	<b>Switzerland</b> 0800-55 58 21
<b>Luxembourg</b> 0800 2618	<b>UK</b> 0800-89 36 77
<b>Mexico</b> 5329- 40000	<b>USA</b> 800-359-2508 Parsec Enterprises, Inc. 7501 N. Harker Dr. Peoria, IL 61650 www.parsecent.com
<b>Netherlands</b> 0800-15 92	

Please fill out this registration card and retain as proof of warranty.

OWNER'S NAME

DATE OF PURCHASE

RETAILER (if known)

NAME/STYLE OF WATCH

SERIAL NUMBER (located on back of watch)

SIGNATURE



hurricane

INSTRUCTION MANUAL

