





TIME


In TIME mode you can set time and calendar information.




Time Warp
Hold for 1 second
in any other mode to
return to TIME.




Switch Time Zones



Chime On/Off




Save Date, Time and Altitude to DATA mode




ALARM


In ALARM mode you can set 4 time alarms, 2 altitude alarms and 1 temperature alarm. Press any button to stop alarm. Time alarm will sound for 55 seconds. Altitude and temperature alarms sound for 5 seconds.



Alarm On/Off





Turn Off All Alarms




S-RUN

In SKI RUN mode you can automatically time your ski run by marking your base altitude.



CHRON


The CHRONOGRAPH can be used to time any activity down to 1/100th of a second.




COMP

The digital COMPASS is self-calibrating and points to the magnetic North Pole. It can be adjusted to point to geographic North (True North).


Always take watch off & keep level




Digital Arrow



Adjust COMPASS to True North.




- 1 Reference a topographic map for your location's declination





Declination: The Variation between the magnetic North Pole and True North.


Re-calibrate Compass (after traveling and after replacing battery)



- 4 Keep watch level and rotate counter-clockwise so arrow is always pointing in same direction.




- 7 View/Recall Compass







ALT 1

In ALTITUDE mode you can view, store and calibrate your current altitude; view and reset your maximum and accumulated altitudes.




Altitude, & feet/meters traveled per minute, Maximum Altitude, Accumulated and On Demand Altitude Reading.




WEATH

WEATHER mode provides a barometer, thermometer, and barometric weather forecaster.


Celsius/Fahrenheit
hPa/inchHg



Set Current Weather



View Forecast and Barometric Pressure



DATA

In DATA mode you can review date, time, and altitude. Save in ALTITUDE or TIME mode.

